

TECHNICAL MANUAL

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND
SPECIAL TOOLS LISTS**

FOR

**SPECTRUM ANALYZER SET ANIUPM-84A
(NSN 6625-00-411-3072)**

**HEADQUARTERS, DEPARTMENT OF THE ARMY
NOVEMBER 1977**

TECHNICAL MANUAL
NO. I 11-6625-359-20P-1

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 7 November 1977

**ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS
FOR**

**SPECTRUM ANALYZER SET AN/ UPM-84A
(NSN 6625-00-411-3072)**

Current as of 22 August 1977

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028-2 (Test) located in the back of the manual. Simply tear out the self-addressed form, fill it out as shown on the sample, fold it where shown, and drop it in the mail.

If there are no blank DA Form 2028-2 (Test) in the back of your manual, use the standard DA Form 2028 (Recommended Changes to Publications and Blank Forms) and forward to the Commander, US Army Electronics Command, ATTN: DRSEL-MA-Q, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

*This manual supersedes so much of TM 11-6625-359-12-1,8 December 1970, as pertains to repair and special tools list.

TABLE OF CONTENTS

		Page	Illus Figure
SECTION	I	Introduction	1
	II	Repair parts list	5
GROUP	00	Spectrum Analyzer Set AN.'UPM-84A.....	5 1
	01	Case assembly, transit (No parts authorized)	
	02	Spectrum Analyzer TS-1916, UPNM-84A (No parts authorized)	
		0201 Cover assembly, dust (No parts authorized)	
		0202 Main assembly.....	7 2
		020201 Power supply assembly (No parts authorized)	
		020202 Oscillator assembly, marker (No parts authorized)	
		020203 Panel assembly, front.....	9 3
		02020301 Attenuator assembly (No parts authorized)	
		020204 Amplifier assembly), IF control band width.....	11 4
		020205 Chassis assembly, wide band	13 5
		020206 Sweeper assembly	15 6
		020207 Chassis assembly, narrow band	17 7
		020208 Fan assembly, a(No parts authorized)	
		020209 Chassis assembly, CRT power supply.	19 8
		020210 Calibrator assembly, assembly	21 9
		020211 Video chassis and potentiometer assembly	23 10
		020212 Plate assembly, transistor (No parts authorized)	
		020213 Harness, wiring (No parts authorized)	
		0203 Head assembly, tuning.....	27 11
		020301 Panel assembly), lower front.....	29 12
		020302 Mixer assembly, P. N A 147648 (No parts authorized)	
		020303 Mixer assembly P N 147805 (No parts authorized)	
		020304 Plate assembly, rear (No parts authorized)	
		02030401 Preamplifier: assembly (No parts authorized)	
		02030402 Filter assembly, low pass (No parts authorized)	
		02030403 Drive assembly, rack (No parts authorized)	
		02030404 Board assembly, oscillator (No parts authorized)	
		020305 Head subassembly, tuning (No parts authorized)	
		02030501 Oscillator assembl1 (No parts authorized)	
		02030502 and drive assembly (No parts authorized)	
	03	Cable assembly, RF, '09817 (No parts authorized)	
	04	Cable assembly, RF, A152044 (No parts authorized)	
	05	Cable assembly, RF, 09816 (No parts authorized)	
SECTION	III	Special tools list (Not applicable)	
	IV	National stock number and part number index.....	30

SECTION I INTRODUCTION

1. Scope

This manual list spares and repairs parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the AN/UPM-84A. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts

lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) Figure number. Indicates the figure number of the illustration on which the item is shown.

(2) Item number. The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) Source code. Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

XD-A support item that is not stocked. When required, item will be procured through normal supply channels.

Code Definition

PA--Item procured and stocked for anticipated or known usage.

XD---A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR-700-42.

(2) Maintenance code. Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code Application/Explanation

O---Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code Application/Explanation

H---The lowest maintenance level capable of complete repair of the support item is the general support level.

Z-- Nonreparable. No repair is authorized.

(3) Recoverability code. Recoverability codes

are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability

Codes Definition

Z---Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.

H-- Reparable item. When uneconomically repairable, condemn and dispose at the general support level.

c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. Part Number,. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e Federal Supply Code for The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. Description Indicates the Federal item name and, if required, a minimum description to identify the item.

g. Unit of Measure (U/M) Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc.). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h Quantity Incorporated in Unit Indicates the quantity of the item used in the breakout chosen on the illustration figure, which is prepared for a functional group, sub functional group, or an assembly.

4. Special Information

a. The following publication pertains to the AN/UPM-84A and its components: TM 11-6625-359-12-1, Spectrum Analyzer, AN/UPM-84A

b. The illustrations in this manual are identical to those published in TM 11-6625-359-40P-I. Only those

parts assigned the third position SMR maintenance code "C" or "0" are listed in the tabular listing; therefore, there may be a break in the item number sequence. Only illustrations containing organizational authorized items appear in this manual.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) First. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) Second. Find the illustration covering the functional group to which the item belongs.

(3) Third Identify the item on the illustration and note the illustration figure and item number of the item.

(4) Fourth. Using the Repair Parts Listing, find the figure and item number noted on the illustration.


b When National stock number or part number is known.

(1) First Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphabetic sequence, cross-referenced to the illustration figure number and item number.

(2) Second After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.





EL2HT001

Figure 1. Spectrum Analyzer Set AN/UPM-84A

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 00 SPECTRUM ANALYZER SET AN/UPM-84A		
1	1	XDOHH		J152060	25778	CASE ASSEMBLY,TRANSIT	EA	1
1	2	PAOHH	6625-00-937-5258	TS1916UPM84A	80058	SPECTRUM ANALYZER TS1916UPM84A.....	EA	1
1	3	PAOHH	5995-00-237-2989	A10817	25778	CABLE ASSEMBLY,RADIO FREQUENCY....	EA	1
	4	PAOHH	5995-00-237-2984	A152044	25778	CABLE ASSEMBLY,RADIO FREOUENCY.....	EA	1
1	5	PAOHH	5995-00-237-29YO	AI09816	25778	CABLE ASSEMBLY.RADIO FREQUENCY.....	EA	1
1	6	PAOZZ	5935-00-226-2103	C147153	81299	ADAPTER,TYPE N.....	EA	1
1	7	XDOZZ		A152430	25778	ADAPTER,BAND K	EA	1
1	8	PAOZZ	6625-00-623-3688	UG1239UPMB4	80058	ADAPTER,BAND KU.....	EA	1
1	9	PAOZZ	6625-00-775-6802	UG1240UPM84	80058	ADAPTER,BAND Q.....	EA	1
1	10	PAOZZ	6625-00-623-3691	UG1241UPM84	80058	ADAPTER.BAND KA.....	EA	1
1	11	XDOZZ		B152421	25778	FILTER,BANCPASS.....	EA	1
1	12	XDODZZ		B52422	25778	FILTER,BANDPASS.....	EA	1
1	13	XDUZZ		B152424	25778	FILTER,AANCPASS.....	EA	1
1	14	PAOZZ	6625-00-625-2669	B152423	25778	FILTER,BANDPASS.....	EA	1
1	15	XDOZZ		H152425	25778	FILTER,BANDPASS.....	EA	1
1	16	PAOZZ	5985-00-943-8634	B8152058	25778	ATTENUATOR	EA	1
EA I	17	PAOZZ	6625-00-221-6507	C152417	25778	ATTENUATOR,BAND KAA	EA	1
1	19	PAOZZ	6625-00-623-3675	C152420	25778	ATTENUATOR, BAND KU.....	EA	1
					5			




EL2HT005

Figure 2. Main Assembly.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 0202 MAIN ASSEMBLY		
2	1	PAOZZ	5960-00-296-0512	5ADP7	81349	ELECTRON TUBE.....	EA	1
2	6	PAOZZ	5355-00-584-4241	MS91528-352B	96906	KNOB	EA	1
2	7	PAOZZ	5355-00-6d0-1357	MS91528-1F2B	96906	KNOB	EA	2
2	8	PAOZZ	5355-00-994-3435	70-2WD2G	99687	KNOB	EA	2
2	19	XDOZZ		A151976	25778	KNOB	EA	3
2	20	XDOZZ		A151977	25770	KNOB	EA	3
2	24	XDOZZ		A151971	25778	KNOB	EA	2
2	25	XDOZZ		A151975	25778	KNOB	EA	2
					7			



FRONT VIEW

EL2HT012

Figure 3. Panel Assembly, Front Upper.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 020203 PANEL ASSEMBLY,FRONT UPPER		
3	3	PAOZZ	5355-00-994-3435	70-2WD2G	99687	KNOB	EA	1
3	5	PAOZZ	5355-00-680-1357	MS91528-1F2B	96906	KNOB	EA	1
3	6	PAOZZ	5355-00-556-015	MS91528-1D2B	96906	KNOB	EA	3
3	7	PAOZZ	6240-00-155-7857	MS25237-328	96906	LAMP,CANDESCENT	EA	1
3	9	XDOZZ		MS90078-15	96906	FUSE ,CARTRIOGE.....	EA	2
					9			




Figure 4. Amplifier Assembly, IF Control Bandwidth.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 020204 AMPLIFIER ASSEMBLY, IF CONTROL		
						BANDWIDTH		
4	8	PADZZ	5960-00-686-8087	M524233-5	96906	SHIELD,,LECTRON TUBE	EA	1
4	9	PADZZ	5960-00-262-0167	12AT7WA	81349	ELECTRON TUBE.....	EA	1
4	16	PADZZ	5960-00-275-7497	6186-6AG5WA	81349	ELECTRON TUBE.....	EA	1
4	17	PADZZ	5960-00-686-8085	MS24233-2	96906	SHIELD, ELECTRON TUBE.....	EA	1
					11			




Figure 5. Chassis Assembly, Wide Band.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
5	1	XDOZZ		MS24233-15	96906	GROUP C20205 CHASSIS ASSEMBLY, WIDE BAND SHIELD.....	EA	4
5	2	PAOZZ	5960-00-676-9016	6922	81349	ELECTRON TLBE	EA	4
					13			




Figure 6. Sweeper Assembly.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 00206 SWEEPER ASSEMBLY		
6	13	PAOZZ	5960-00-686-8087	MS24233-5	96906	SHIELD,ELECTRON TUBE.....	EA	1
6	14	PAOZZ	5960-00-852-0235	6BQ5	81349	ELECTRON TUBE.....	EA	1
6	21	PAOZZ	5960-00-686-7952	T3-3031H	98978	SHIELD,ELECTRON TUBE.....	EA	2
6	22	PAOZZ	5960-00-228-3793	5718	81349	ELECTRCN TUBE.....	EA	3
6	28	PAOZZ	5960-00-686-8119	MS24233-1	96906	SHIELD,ELECTRON TUBE.....	EA	1
6	29	PAOZZ	5960-00-262-1357	5654- 6AK5W	81349	ELECTRON TUBE.....	EA	1
					15			




Figure 7. Chassis Assembly, Narrow Band.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 020207 CHASSIS ASSE.MBLY, NARRO BANG		
7	1	PAOZZ	5960-00-686-8085	MS52433-2	96906	SHIELD,ELECTRON TUBE.....	EA	4
7	2	PAOZZ	596 00-547-7004	6AH6WA	81349	ELECTRON TUBE.....	EA	2
7	3	XDOZZ		5750-6BE6W	81349	ELECTRCN TUBE.....	EA	2
7	9	PAOZZ	596-D00-686-8119	MS24233-1	96906	SHIELD.ELECTRON TUBE.....	EA	1
7	10	PAOZZ	5960-00-262-1357	5654-6AK5W	81349	ELECTRON TUBE.....	EA	1
					17			





Figure 8. Chassis Assembly, CRT Power Supply

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 020209 CHASSIS ASSEMBLY, CRT POWER		
						SUPPLY		
8	5	PAOZZ	5960-00-2961104	6098/6AR6WA	81349	ELECTRON TUBE.....	EA	1
8	22	PAOZZ	5960-00-188-8612	1Z2	81349	ELECTRON.TUBE.....	EA	2
					19			



EL 2HT024

Figure 9. Calibrator Assembly, Crystal.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP O2O210 CALIBRATOR ASSEMBLY.CRYSTAL		
9	1	PAOZZ	5960-00-262-0167	12AT7WA	81349	ELECTRCN TUBE.....	EA	2
9	3	PAOZZ	5960-00-082-4139	5751	81349	ELECTRON TUBE.....	EA	1
9	10	PAOZZ	5960-00-686-8119	M524233-1	96906	SHIELD,ELECTRUN TUBE.....	EA	1
9	11	PAOZZ	5960-00-262-1357	5654-6AK5W	61349	ELECTRCN TUBE.....	EA	1
9	16	PAOZZ	5960-00-752-5857	HS24233-6	96906	SHIELD,ELECTRON TUBE.....	EA	1
9	17	PAOZZ	5960-00-188-3915	5763	81349	ELECTRCN TUBE.....	EA	1
9	23	PAOZZ	5960-00-686-8087	MS24233-5	96906	SHIELD,ELECTRON TUBE.....	EA	3
					21			




Figure 10. Video Chassis and Potentiometer Assembly.

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6) DESCRIPTION	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 020211 VIDEO CHASSIS AND POTENTIOMETER ASSEMBLY		
10	1	PAOZZ	5960-00-686-8085	MS24233-2	96906	SHIELD.ELECTRON TUBE.....	EA	2
10	2	PAOZZ	5960-00-542-7004	6AH6WA	81349	ELECTRON TUBE.....	EA	2
10	3	PAOZZ	5960--00686-8087	MS24733-5	86906	SHIELD,ELECTRON TUBE.....	EA	6
10	4	PAOZZ	5960-00-985-8986	6ANSA	81349	ELECTRON TUBE.....	EA	2
10	5	PAUZZ	5960-00-666-8119	MS24233-1	96906	SHIELD,ELECTRON TUBE.....	EA	1
10	6	PAOZZ	5960-00-237-6917	5725-6AS6W	81349	ELECTRON TUBE.....	EA	1
10	7	PAOZZ	5960-00-26Z-0167	12AT7WA	81349	ELECTRON TUBE.....	EA	1
10	11	PAOZZ	5960-00-262-0210	5814A	81349	ELECTRCN TUBE.....	EA	3
23/(24 blank)								





Figure 11. Head Assembly, Tuning (Sheet 1 of 2)





Figure 11. Head Assembly, Tuning (Sheet 2 of 2).

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
						GROUP 0203 HEAD ASSEMBLY,TUNING		
11	3	PAOZZ	5355-00-619-4668	MS91528-2N2B	96906	KNOB	EA	1
11	4	PAOZZ	5355-00-579-6390	MS91528-2F28	96906	KNOB	EA	1
11	5	PAOZZ	5355-00-523-8278	MS95128-4S2B	96906	KNOB	EA	1
11	14	PAOZZ	5355-00-556-0145	MS9152B-1K28	96906	KNOB,	EA	1
11	26	PAOZZ	6240-00-155-8707	MS15571-6	96906	LAMP.INCANDESCENT.....	EA	4
11	32	PAOZZ	5960-00-647-2760	6AF4A	80131	ELECTRON TUBE.....	EA	2
11	47	PAOZZ	5960-00-051-0132	7049ZV1009	82199	ELECTRON TUBE.....	EA	1
					27			




Figure 12. Panel Assembly, Lower Front (Sheet 1 of 2)
28

SECTION II

TM11-6625-359-20P-1

(1) ILLUSTRATION		(2)	(3)	(4)	(5)	(6)	(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	PART NUMBER	FSCM	DESCRIPTION USABLE ON CODE	U/M	QTY INC IN UNIT
12	4	PAOZZ	5920-00-281-0225	F02A250V6AS	81349	GROUP 020301 PANEL ASSEMBLY,LOWER FRONT FUSE	EA	2
					29			

NATIONAL STOCK NUMBER INDEX AND PART NUMBER INDEX

NOTE: LATEST NATIONAL STOCK NUMBER AND PART NUMBER ASSIGNMENTS ARE INCLUDED AT END OF

			<u>INDEX</u>			
STOCK NUMBER	FIG.	ITEM	STOCK NUMBER	FIG.	ITEM	
5960-00-051-0132	11	47	5355-00-584-4241	2	6	
5960-00-082-4139	9	3	5355-00-619-4668	11	3	
6240-00-155-7857	3	7	6625-00-623-3675	1	19	
6240-00-155-8707	11	26	6625-00-623-3688	1	8	
5960-00-188-39i5	9	17	6625-00-625-2669	1	14	
5960-00-188-8612	8	22	5960-00-647-2760	11	32	
6625-00-213-2719	1	18	5960-00-676-9016	5	2	
6625-00-221-6507	1	17	5365-00-680-1357	2	1	
5960-00-228-3793	6	22	5355-00-680-1357	3	5	
5995-00-237-2984	1	4	5960-00-686-7952	6	21	
595-00-237-2989	1	3	5960-00-686-8085	4	17	
5995-00-237-2990	1	5	5960-00-686-8085	1	1	
5960-00-237-69L 7	10	6	5960-00-686-8085	10	1	
596-000262-0167	4	9	5960-00-686-8087	4	8	
5960-00-262-0167	9	1	5960-00-686-8081	6	13	
5960-00-262-0167	10	7	5960-00-686-8087	9	23	
5960-00-262-0210	10	18	5960-00-686-8087	10	3	
5960-00-262-1357	6	29	5560000-686-8i19	7	9	
5960-00-262-1357	9	11	5960-00-686-8119	9	10	
5960-00-215-7497	4	16	5960-00-686-8119	10	5	
5920-U0-281-0225	12	4	5960-00-752-5857	9	16	
5960-00-296-0512	2	1	6625-00-775-6802	1	9	
5355-00-523-8278	11	5	5960-00--85-0235	6	14	
5960-00-542-7004	7	2	6625-00-937-525B	1	2	
5960-00-542-7004	10	2	5985-00-943-8634	1	16	
5355-00-556-0145	11	14	5960-00-985-8986	10	4	
5355-00-556-015L	3	6	5355-00-994-3435	2	8	
5355-00-519-6390	11	4	5355-00-994-3435	3	3	

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
A109816	25778	1	5	MS91528-1F2B	96906	3	5
A109817	25778	1	3	MS91528-1K2B	96406	11	14
A151971	25778	2	24	MS91528-2F2B	96906	11	4
A151975	25778	2	25	MS91528-2N2B	96906	11	3
A5L1L56	25778	2	19	MS91526-3S2B	96906	2	6
A151977	25778	2	20	MS91528-452B	96906	11	5
A152044	25778	1	4	TS1916UPM84A	80058	1	2
A152430	25778	1	7	T3-3031H	98978	6	21
8152058	25778	1	16	UG1239UPM84	80058	1	8
8152421	25778	1	11	UG1240UPM84	80058	1	9
8152422	25778	1	12	UG1241UPM84	80058	1	10
8152423	25778	1	14	1Z2	81349	8	22
8152424	25718	1	13	12AT7WA	81349	4	9
B152425	25778	1	15	12AT7WA	81349	9	1
C147853	81299	1	12	12AT7WA	81349	10	7
C152417	25778	1	17	152414	25778	1	16
C152420	25717	1	19	5ADP7	81349	2	1
F02A250V6AS	81349	12	4	5654-6AK5W	81349	6	29
J152060	25778	1	1	5654-6AK5W	81349	7	10
MS15571-6	96906	11	26	5654-6AK5W	81349	9	11
MS24233-1	96906	6	28	5718	61349	6	22
MS24233-1	96906	7	9	5725-6AS6W	81349	10	6
M524233-1	96906	9	10	5150-6BE6W	81349	7	7
MS24233-1	96906	10	5	5751	81349	9	3
MS24233-15	96906	5	1	5763	81349	9	17

NATIONAL STOCK NUMBER AND PART NUMBER INDEX

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
MS24233-2	96906	4	17	5814A	81349	10	11
MS24233-2	96906	7	1	6AF4A	81349	11	32
MS24233-2	96906	10	1	6AH6WA	81349	7	2
MS24233-5	86906	10	3	6AH6WA	81349	10	2
MS24233-5	969J6	4	8	6ANBA	81349	10	4
MS24233-5	96906	6	13	6BQW	81349	6	14
MS24233-5	96906	9	23	6098/6AR6WA	81349	8	5
MS24233-6	96906	9	16	6186-6AG5WA	81349	4	16
MS25231-32d	96906	3	7	6922	81349	9	2
MS90078-15	9690b	3	9	70-2WD2G	99687	2	8
MS91528-1D2B	96906	3	6	70-2WD2G	99687	3	3
MS91528-1F2B	96906	2	7	7049ZV1009	82199	11	471

LATEST NATIONAL STOCK NUMBER ASSIGNMENTS

STOCK NUMBER	FIG.	ITEM
5935-00-226-2103	1	6
5960-00-296-1104	8	5
6625-00-623-3691	1	10

By Order of the Secretary of the Army:

Official:

J. C. PENNINGTON
Brigadier General, United States Army
The Adjutant General

BERNARD W. ROGERS
General United States Army
Chief of Staff

DISTRIBUTION

Active Army

USAINSC.(2)	UJSAARMS (2)
COE (1)	USAIS (2)
TSG 1)	USAES (2)
USAARENBD (1)	AD (1) except
DARCOM (1)	SAAD (30)
TECOM (2)	LBAD (14)
USACC (4)	TOAD (14)
TRADOC (2)	SHAD (3)
OS Maj Cmd (4)	USA Dep (2)
MDW (1)	Sig Sec USA Dep (2)
Armies (2)	Sig Dep (2)
Corps (2)	MAAG (1)
HISA (Ft Monmouth) (33)	USARMIS (1)
Ft G611cm (10)	USAFRDAA (1)
Ft Gordon (10)	USAERDAW(1)
Ft Huachuca (10)	USSATC&S (5)
Ft Carson (5)	Sig FLDMS (1)
Ft Richardson (ECON Ofc) (2)	Units org under fol TOE: 1 ea.
Svc Colleges (1)	11-500(AA-AC)
USASIGS (5)	29-134
USAICS (3)	29-136
USAADS (2)	32-109
USAFAS (2)	55-458

ARNG& USAR: None

For explanation of abbreviations, used see AR 310-50.

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS



THEN... JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

SOMETHING WRONG WITH THIS PUBLICATION?

FROM: (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 11-5825-270-10

PUBLICATION DATE

23 Jul 81

PUBLICATION TITLE

Radio Frequency R-2176/FRN

BE EXACT... PIN-POINT WHERE IT IS

PAGE NO.

PARA-GRAPH

FIGURE NO.

TABLE NO.

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG PERFORATED LINE

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 JUL 79

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

This fine document...

Was brought to you by me:



[Liberated Manuals -- free army and government manuals](#)

Why do I do it? I am tired of sleazy CD-ROM sellers, who take publicly available information, slap “watermarks” and other junk on it, and sell it. Those masters of search engine manipulation make sure that their sites that sell free information, come up first in search engines. They did not create it... They did not even scan it... Why should they get your money? Why are not letting you give those free manuals to your friends?

I am setting this document FREE. This document was made by the US Government and is NOT protected by Copyright. Feel free to share, republish, sell and so on.

I am not asking you for donations, fees or handouts. If you can, please provide a link to liberatedmanuals.com, so that free manuals come up first in search engines:

<A HREF=<http://www.liberatedmanuals.com/>>Free Military and Government Manuals

- Sincerely
Igor Chudov
<http://igor.chudov.com/>
- [Chicago Machinery Movers](#)